Hazards of Confined Spaces

WorkSafeBC

WORKING TO MAKE A DIFFERENCE

worksafebc.com

BK80 cover.indd 1 12/4/08 8:46:14 AM

About WorkSafeBC

WorkSafeBC (the Workers' Compensation Board) is an independent provincial statutory agency governed by a Board of Directors. It is funded by insurance premiums paid by registered employers and by investment returns. In administering the *Workers Compensation Act*, WorkSafeBC remains separate and distinct from government; however, it is accountable to the public through government in its role of protecting and maintaining the overall well-being of the workers' compensation system.

WorkSafeBC was born out of a compromise between B.C.'s workers and employers in 1917 where workers gave up the right to sue their employers or fellow workers for injuries on the job in return for a no-fault insurance program fully paid for by employers. WorkSafeBC is committed to a safe and healthy workplace, and to providing return-to-work rehabilitation and legislated compensation benefits to workers injured as a result of their employment.

WorkSafeBC Prevention Information Line

The WorkSafeBC Prevention Information Line can answer your questions about workplace health and safety, worker and employer responsibilities, and reporting a workplace accident or incident. The Prevention Information Line accepts anonymous calls.

Phone 604 276-3100 in the Lower Mainland, or call 1 888 621-7233 (621-SAFE) toll-free in British Columbia.

To report after-hours and weekend accidents and emergencies, call 604 273-7711 in the Lower Mainland, or call 1 866 922-4357 (WCB-HELP) toll-free in British Columbia.

BKB0 cover.indd 2 12/4/08 8:46:16 AM

Hazards of Confined Spaces

WorkSafeBC
WORKING TO MAKE A DIFFERENCE
worksafebc.com

BK80 guts COLOUR.indd AA1 12/5/08 10:24:20 AM

WorkSafeBC Publications

Many publications are available on the WorkSafeBC web site. The Occupational Health and Safety Regulation and associated policies and guidelines, as well as excerpts and summaries of the *Workers Compensation Act*, are also available on the web site: WorkSafeBC.com.

Some publications are also available for purchase in print:

Phone: 604 232-9704

Toll-free phone: 1 866 319-9704

Fax: 604 232-9703

Toll-free fax: 1 888 232-9714

Online ordering: WorkSafeBC.com and click on Publications; follow the links for ordering

©2004, 2006, 2008 Workers' Compensation Board of British Columbia.
All rights reserved. The Workers' Compensation Board of B.C. encourages the copying, reproduction, and distribution of this document to promote health and safety in the workplace, provided that the Workers' Compensation Board of B.C. is acknowledged. However, no part of this publication may be copied, reproduced, or distributed for profit or other commercial enterprise, nor may any part be incorporated into any other publication, without written permission of the Workers' Compensation Board of B.C.

2008 edition

Library and Archives Canada Cataloguing in Publication Data
Main entry under title:
Hazards of confined spaces. – 2004-

Irregular.
ISSN 1712-1442 = Hazards of confined spaces

1. Industrial hygiene – British Columbia. 2. Industrial safety – British Columbia. 3. Work environment – British Columbia. I. Workers' Compensation Board of British Columbia.

HD7659.B7.H49 363.11'6'09711 C2004-960123-7

Contents

What is a confined space? **1**

Hazardous atmospheres **4**

Oxygen: too little or too much 5

Toxic atmospheres 7

Explosive atmospheres 9

Gases that may be in your workplace 12

Physical hazards **14**

Loose and unstable materials 14

Slip, trip, and fall hazards 14

Falling objects 15

Moving parts of equipment and machinery 15

Electrical shock 15

Substances entering through piping 16

Poor visibility 16

Temperature extremes 16

Noise 17

Risk of drowning 17

Confined space entry program **18**

BK80 guts COLOUR.indd i 12/5/08 10:24:21 AM

Acknowledgments

This book would not have been possible without the generous assistance of many people and organizations. WorkSafeBC thanks them for their review of this book and valuable contributions of knowledge and time. WorkSafeBC is grateful to Domtar, Inc. and Petro-Canada Burrard Products Terminal for arranging the photography for this book.

About this book

This booklet is intended for workers and employers in industries where there are confined spaces. The examples and hazard alerts are taken from a variety of industries. In addition to this booklet, there are three versions with more specific information about different industries:

- *Hazards of Confined Spaces for Shipping and Transportation Industries* (order number BK81)
- *Hazards of Confined Spaces for Food and Beverage Industries* (order number BK82)
- *Hazards of Confined Spaces for Municipalities and the Construction Industry* (order number BK83)

BK80 guts COLOUR.indd ii 12/5/08 10:24:21 AM

What is a confined space?

A confined space is an enclosed or partially enclosed area that is big enough for a worker to enter. It is not designed for someone to work in regularly, but workers may need to enter the confined space for tasks such as inspection, cleaning, maintenance, and repair. A small opening or a layout with obstructions can make entry and exit difficult and can complicate rescue procedures.

Entry into confined spaces can be very hazardous. Unless proper training, equipment, and procedures are in place, workers must not be allowed to enter such spaces. **A worker is considered to have entered a confined space just by putting his or her head across the plane of the opening**. If the confined space contains toxic gases, workers who are simply *near* the opening may be at risk. Often the toxic gases are under pressure because of heat inside the confined space or when gases are generated inside the space. As a result, the concentration of toxic gases near the entrance to the confined space can be high enough to cause death.

It is vital to identify all confined spaces in any workplace. Examples of confined spaces include tanks, silos, storage bins, process vessels, pipelines, sewers, underground utility vaults, and vats – in short, any area that can have a "confined" atmosphere. Workers have died because they did not know they were entering a confined space with a hazardous atmosphere and therefore did not take the necessary precautions.

In addition, an enclosed area in which workers do not normally work could have air that may be hazardous to breathe or the work activity could cause a hazardous atmosphere to develop. Even though rescue would not be complicated by the design of the space (and it does not therefore fit the definition of a confined space), the space may still be **deadly** without air testing and a supply of clean air.

Confined spaces in your workplace

Examples of confined spaces:

- Tanks
- Boilers
- Vats
- Kilns
- Vaults
- Silos
- Pipelines
- Sewers
- Manure pits
- Storage bins
- Double hulls
- Pumping stations
- Pits, sumps
- Vessels
- Manholes
- Water reservoirs
- Other similar spaces

BK80 guts COLOUR.indd 1 12/5/08 10:24:21 AM

The flotation compartment of a barge is a confined space that may not have enough oxygen to sustain life.



This process vessel at a pulp mill is a confined space. One worker died inside the vessel from lack of oxygen and another died while breathing the air through the opening.



This water cistern is a confined space with limited access and ventilation. While a waterproof coating was being applied, flammable vapours were generated. The vapours ignited, causing an explosion.

BK80 guts COLOUR.indd 2 12/5/08 10:24:21 AM

The employer is responsible for determining if confined spaces are present in the workplace. If there are any access points, then they must be secured against entry, or signs (or other effective means) must be used to identify the space and warn workers of the hazards. However, if you think an area without identification is actually a confined space (see previous page), then DO NOT ENTER unless you **know** it is safe to do so.

This book describes the main types of hazards found in confined spaces. Confined spaces may contain hazardous atmospheres, including insufficient oxygen, toxic (poisonous) air, or an explosive atmosphere. These spaces may also have physical hazards that may result, for example, in workers falling, being crushed or buried, or drowning. These hazards may not be obvious. All confined spaces must be carefully assessed to identify every hazard. These assessments must be done by a qualified person familiar with the confined space and the work to be done in that space.

The hazard alerts in this book are based on real accidents that occurred in workplaces around the world.

After reading this book, you should be aware that the air in a confined space must be tested and that all hazards within the space must be identified and safe entry procedures controlling the hazards must be followed before anyone enters. This book is not intended to explain how to eliminate or control all the hazards. A qualified person must develop written procedures for eliminating or safeguarding the hazards. The Occupational Health and Safety Regulation, Part 9, sets out requirements for confined space entry. For more information on confined space entry, visit the Safety at Work section of the WorkSafeBC web site, WorkSafeBC.com.

BK80 guts COLOUR.indd 3 12/5/08 10:24:22 AM

Hazard alert



A worker was performing welding inside a titanium tank. (The picture shows a cut-away view.) Argon gas was being used as a shielding for the weld The worker was not wearing a respirator. He was found unconscious in the tank and died from lack of oxygen.

Hazardous atmospheres

The atmosphere in a confined space may be hazardous for several reasons. The air may have too little or too much oxygen. The atmosphere may be toxic or explosive. Pages 4–13 describe some of the dangers of hazardous atmospheres. Confined spaces with hazardous atmospheres could also have some of the physical hazards described on pages 14–17.

Once a confined space is identified, its atmosphere must be hazard-rated as **HIGH**, **MODERATE**, or **LOW**. The hazard rating of a confined space must be determined by a qualified person after considering the design, construction, and use of the confined space, the work activities to be performed, and all required engineering controls.

High-hazard atmosphere

An atmosphere that may expose a worker to risk of death, injury, or acute illness, or otherwise impair a worker's ability to escape unaided from a confined space if the ventilation system or respirator fails.

Moderate-hazard atmosphere

An atmosphere that is not clean, respirable air but is not likely to impair a worker's ability to escape unaided from a confined space if the ventilation system or respirator fails.

Low-hazard atmosphere

An atmosphere that is shown by pre-entry testing or is otherwise known to contain clean, respirable air immediately prior to entry into a confined space, and that is not likely to change during the work activity.

BK80 guts COLOUR.indd 4 12/5/08 10:24:26 AM

Oxygen: too little or too much

Lack of oxygen is a leading cause of death among workers entering confined spaces. Low oxygen levels cannot be detected by sight or smell. You must test the air for this hazardous condition. A very low level of oxygen can damage the brain and cause the heart to stop after a few minutes.

What causes oxygen deficiency?

Here are some common causes of oxygen deficiency (not enough oxygen) in a confined space:

- Oxygen is used up when metals rust.
- Oxygen is used up during combustion – for example, by propane space heaters, during cutting or welding, and by internal combustion engines.
- Oxygen can be replaced by other gases – for example, welding gases or gases forced into the space to prevention corrosion.
- Micro-organisms use up oxygen – for example, in sewer lines and fermentation vessels.

Too much oxygen is not as common a hazard as low oxygen, but it is also dangerous. Too much oxygen greatly increases the risk of fire or explosion in the confined space. Materials that would not normally catch fire or burn in normal air may do so extremely quickly and easily where there is a high level of oxygen.

The only way to know how much oxygen is present in a confined space is to use an oxygen monitor. **The monitor must be in good working order and properly maintained and calibrated. The alarm must be set at the right level**. Someone trained to use the monitor must test the air before anyone enters the confined space.

An oxygen monitor shows oxygen levels as a percentage of the air. Air contains 20.9% oxygen.

NOTE: As the elevation increases, the amount of oxygen in the air decreases. However, the percentage reading on the oxygen monitor does not change with elevation. Therefore, always consult with a qualified person to determine safe entry procedures. The qualified person will take elevation into account.

Test the oxygen content in the air with an oxygen monitor before you enter a confined space.

BK80 guts COLOUR.indd 5 12/5/08 10:24:26 AM

Hazard alert

Not enough oxygen

Two men collapsed and died while helping to clean an oil drilling rig that had been sealed for five years. These rigs are typically filled with seawater or mud for ballast. The workers entered the leg of the rig to check for damage. The two victims were not wearing respirators. It is not known whether they were monitoring the air quality in the confined space. The air in the leg did not have enough oxygen to sustain life.

The monitor should be tested in clean outside air. If the reading is above or below 20.9% oxygen, there may be a problem with the oxygen sensor or with the calibration of the unit. Do not use this monitor for testing inside the confined space, and do not enter the confined space until a properly calibrated monitor is used.

Clean outside air contains 20.9% oxygen. If the air in the confined space is anything other than 20.9%, the reason should be investigated by a qualified person to ensure the space is safe to enter. It is vitally important to understand what is causing the change in oxygen level. The reason must be identified before workers are allowed to enter the space. For example, many toxic gases present a high hazard to workers even when the concentration is low enough to cause only a very small displacement of oxygen. With some common solvents, a 0.1% change in the oxygen reading could mean the presence of enough toxic gas to cause death or serious injury.

Working in an atmosphere with oxygen levels between 14% and 17% can produce impaired judgment, dizziness, fatigue, and collapse. In oxygen levels lower than this, the one breath you take could have so little oxygen that your muscles can't respond and you won't have enough strength to escape even if you are still conscious. The only safe way to find out whether air in a confined space has enough oxygen is to use a properly calibrated and maintained monitor.

Workers must not enter a confined space containing less than 19.5% oxygen without taking appropriate precautions, including the use of supplied-air respirators.

BK80 guts COLOUR.indd 6 12/5/08 10:24:26 AM

Toxic atmospheres

Contaminants in the air can result in an atmosphere that is toxic to workers and may result in injury or death. Some toxic gases typically found in confined spaces are listed in the table on pages 12–13.

In the past, miners would take canaries down into coal mines, since these small birds react quickly to carbon monoxide, a deadly gas. If the canaries breathed a small amount of the gas, they would sway on their perches before falling. This gave miners warning that the deadly gas was present. Today, miners have monitors to let them know when there are toxic substances in the atmosphere.

The concentration of the substance inside the confined space must be determined using a recently calibrated and properly set up air monitor with the correct sensor. Such an air monitor may sound an alarm that will alert the worker before the allowable exposure limit is reached.

Hazard alert

Worker dies while cleaning vat

A worker was overcome by a toxic atmosphere when cleaning a vat used to mix chemicals. He was found unconscious inside the vat. Co-workers pulled him back and tried CPR but could not revive him. The vat contained chemicals used in the manufacture of adhesives, sealants, and coatings.

In most cases, mechanical ventilation such as fans must be used to ventilate the space, bringing in clean outside air. Additionally, the harmful substance must be eliminated wherever practicable. Air testing and ventilation are the best ways to ensure that workers are not placed at risk from hazardous atmospheres.

At certain concentrations, some substances become **immediately dangerous to life and health** (IDLH). At these levels, even a brief exposure can cause permanent health effects such as brain, heart, or lung damage. Or the substance may make workers dizzy or unconscious so that they cannot escape from the confined space. Some substances have very low IDLH levels. For example, the IDLH level for hydrogen sulfide is only 100 ppm (parts per million).

A list of IDLH levels can be found in the *NIOSH Pocket Guide to Chemical Hazards*, from the U.S. National Institute for Occupational Safety and Health. The *Pocket Guide* can be ordered from NIOSH or downloaded from their web site: **http://www.cdc.gov/niosh/npg/npg.html**

For more information on allowable occupational exposure limits, refer to OHS Guideline G5.48-1, part of the Occupational Health and Safety Regulation materials on the WorkSafeBC web site, WorkSafeBC.com.

BK80 guts COLOUR.indd 7 12/5/08 10:24:26 AM

Hazard alert

Workers overcome by toxic vapours

Three maintenance workers were found unconscious in a concrete silo. They had been overcome by a toxic vapour as they applied a rubber coating to the inside of the silo. None of the workers was wearing a respirator, and the workspace was not ventilated. A safety inspector stated that they would not have survived if they had been left inside the silo much longer before rescue.

As a result of liquids and solids inside the confined space ...

Liquids may produce hazardous atmospheres if they evaporate – for example, liquid fuel in a tank producing vapours. Dangerous conditions can develop when pockets of gas in waste materials are disturbed during cleaning. For example, an organic material such as manure sludge can release the toxic gas hydrogen sulfide when manure pits are cleaned out. Rotting pulp in tanks also creates hydrogen sulfide. If grains in silos ferment, they use up oxygen and produce deadly gases.

As a result of work done inside the confined space ...

In one-third of accidents involving harmful gases or lack of oxygen, the danger was not present in the confined space when the worker first entered it. Rather, the work in the confined space created the hazardous atmosphere.

Activities that may lead to the release of harmful substances into the air include grinding, descaling, insulation removal, metal spray applications, rubber lining, painting, fibre-glassing, cutting, welding, and the use of internal combustion engines. Cleaning agents may be toxic, may react with tank residues, or may release a deadly gas from porous surfaces inside the space.

Cleaning a tank that contains dusts can cause the dust to become airborne and create a hazardous atmosphere.



Local exhaust draws the welding fumes out of the confined space. Clean outside air is pumped in.

BK80 guts COLOUR.indd 8 12/5/08 10:24:27 AM

As a result of contamination from outside sources ...

A confined space may be located next to a source of a hazardous contaminant. The contaminant could enter the confined space through porous walls, such as those that may be found in sewers or trenches, or through difficult-to-seal openings such as conduits. Normally, mechanical ventilation is set up to bring outside air into the confined space. If the intake hose is located beside a running vehicle or equipment with an internal combustion engine, the intake hose brings in exhaust fumes.

Explosive atmospheres

Three elements are necessary for a fire or explosion to occur: oxygen, flammable material (fuel), and an ignition source.



Oxygen

Air normally contains 20.9% oxygen, enough oxygen for a fire. However, a higher level of oxygen increases the likelihood of material burning. Air is considered oxygen-enriched at levels above 23%. Enrichment can be caused by improper isolation of oxygen lines, ventilation of the space with oxygen instead of air, or leaks from welding equipment.

BK80 guts COLOUR.indd 9 12/5/06 10:24:27 AM

Fuel

Fires and explosions in confined spaces are often caused by gases or vapours igniting. Coal dust and grain dusts may explode when a certain level of dust in the air is reached.

NOTE: Two or more chemicals may react with each other and become explosive.

Containers of fuels such as gasoline and propane should not be taken into a confined space as fuel can easily burn or explode.

Here are some other common substances that can cause explosions or fires in confined spaces:

- Acetylene gas from leaking welding equipment
- Methane gas and hydrogen sulfide gas produced by rotting organic wastes in sewers or tanks
- Hydrogen gas produced by contact between aluminum or galvanized metals and corrosive liquids
- Grain dusts, coal dust
- Solvents such as acetone, ethanol, toluene, turpentine, and xylene, which may have been introduced into the space through spills or by improper use or disposal

Hazard alert

Two workers injured in a natural gas explosion

Two workers were working in an underground natural gas pipeline vault containing valves and regulating equipment. They were removing concrete forms from the newly installed vault doors. Natural gas had leaked into the vault and was trapped there partly because workers had covered most of the opening with plywood. They were using an impact wrench which ignited the natural gas. They had not tested the vault for gas before entering the confined space.

A trained person must test the atmosphere for gases and vapours that will burn or explode. You cannot always see or smell these dangerous gases and vapours. If any measurable explosive atmosphere is detected, the air must be further evaluated by a qualified person to ensure that it is safe to enter the confined space.

BK80 guts COLOUR.indd 10 12/5/08 10:24:27 AM

Ignition sources

Ignition sources include:

- Open flames
- Welding arcs
- Hot surfaces
- Lighting
- Sparks from metal impact
- Arcing of electrical motors
- Discharge of static electricity
- Chemical reaction

Many processes can generate static charge, including steam cleaning, purging, and ventilation procedures. To reduce the risks from these ignition sources, use non-sparking tools and ensure all equipment is bonded or grounded properly.



*An opening that is **not** a doorway will help you recognize a confined space in your workplace. There may be hazardous gases inside the space from the contents, or if cleaning or welding is being done inside the space, hazardous gases might be produced. If there isn't sufficient ventilation, you may not have enough oxygen to breathe. You may fall or be crushed by machinery inside the space. Before anyone enters a confined space such as this one, safety precautions must be in place. These include testing the atmosphere and ventilating if necessary.*

BK80 guts COLOUR.indd 11 12/5/08 10:24:27 AM

Gases that may be in your workplace

Contaminant	*What is the MAIN danger?*	*What does it look/ smell like?*
Argon (Ar)	Displaces oxygen May accumulate at bottom	Colourless, odourless
Carbon dioxide (CO_2)	Displaces oxygen Toxic May accumulate at bottom	Colourless, odourless
Carbon monoxide (CO)	Toxic — asphyxiant (causing suffocation)	Colourless, odourless (NO WARNING)
Chlorine (Cl_2)	Toxic — lung and eye irritant May accumulate at bottom	Greenish yellow colour; sharp pungent odour
Gasoline vapours	Fire and explosion May accumulate at bottom	Colourless; sweet odour
Hydrogen sulfide (H_2S)	Extremely flammable Very toxic — causes lung failure May accumulate at bottom	Colourless; rotten egg odour*
Methane (CH_4)	Fire and explosion May accumulate at top	Colourless, odourless (NO WARNING)
Nitrogen (N_2)	Displaces oxygen	Colourless, odourless (NO WARNING)
Nitrogen dioxide (NO_2)	Toxic — severe lung irritant May accumulate at bottom	Reddish brown; pungent odour
Sulfur dioxide (SO_2)	Toxic — severe lung irritant May accumulate at bottom	Colourless; rotten, suffocating odour
Oxygen (O_2)	Low levels — asphyxiant High levels — causes spontaneous combustion, explosion	Colourless, odourless

* Exposure deadens the sense of smell, which means you could be walking TOWARD rather than AWAY from the source and not know it!

NOTE: Combining chemicals may result in a toxic gas being released. Always read the Material Safety Data Sheet to get the information you need about mixing two products.

BK80 guts COLOUR.indd 12 12/5/08 10:24:28 AM

Explosive or flammable?	*Industry examples*
NO	Used when welding inside confined space.
NO	Fermentation process in wine storage and fermentation tanks.
YES	Produced by gas or propane.
NO	Could leak into confined space from nearby tanks or piping containing chlorine; piping inflows.
YES, VERY!	Use of gasoline inside a confined space; vapours from spills of gasoline nearby.
YES	Rotting matter has bacteria generating H_2S. In pulp and paper mills, sewers, treatment plants.
YES, VERY!	Rotting matter will generate methane. In sewers, storage tanks.
NO	Inerting a vessel to displace the oxygen to prevent corrosion. In boilers, storage tanks.
NO	Produced by internal combustion engines, tools, and equipment that run on gasoline, propane, or diesel.
NO	Nearby tanks or piping containing sulfur dioxide that could leak; piping inflows.
Supports combustion	Bacteria, rusting, and internal combustion engines will use up oxygen; other gases can replace oxygen. In ballast tanks, boilers, double hulls, utility vaults, septic tanks, vats, manure pits, wine storage and fermentation tanks, reaction vessels, storage tanks, fuel tanks, tank cars, tank trucks, kilns. Welding inside any confined space may decrease the level of oxygen.

BK80 guts COLOUR.indd 13 12/5/08 10:24:28 AM

Physical hazards

Loose and unstable materials

Whenever unstable solids made of small particles like sand or grain are stored in enclosures, there is a danger of the materials flowing onto workers and trapping or burying them. Examples of these confined spaces are sand bins, wood chip or sawdust bins, storage or grain silos, and potash feed systems.

Granular materials, particularly if moist, can form bridges (or shoulders) above workers. If jarred, these can collapse onto a worker.

Bins and hoppers in which materials are conveyed or augered into the bin are particularly dangerous. A worker may be trapped or crushed when material is accidentally discharged into an empty bin or hopper.

The design of these confined spaces may increase the danger of being trapped or buried. For example, in an empty hopper with a floor that slopes steeply to a vertical chute, a worker can slide into the chute and become trapped there.

Hazard alert

A young worker was feeding sand into a large mixing silo to make concrete when the mixture stopped flowing. When he stamped his foot on the clogged sand, he fell into the silo. A second worker climbed into the silo to keep the sand from covering the first worker's head and he was also trapped. Both were rescued by the rescue squad.

Wherever there are loose, unstable materials that could trap or bury you, a qualified person must inspect the space and assess the hazards. Do not enter until the hazard has been eliminated or controlled. Specific training and safety precautions must be in place before you enter.

Slip, trip, and fall hazards

The space you are about to enter may have a hatchway that is difficult to squeeze through, and ladders for ascending or descending. You are therefore at risk of falling while getting into the space as well as while you are inside. In addition, the flooring of tanks or other wet environments or the rungs of a ladder may be very slippery.

If the hazard cannot be eliminated and there is a danger of falling from a height, a fall protection system (such as guardrails or a harness and lifeline) may be needed.

BK80 guts COLOUR.indd 14 12/5/08 10:24:28 AM

Falling objects

In a confined space there may be the danger of being struck by falling objects such as tools or equipment, particularly if access ports or workstations are located above workers.

If workers might be exposed to the hazard of falling objects, safe work procedures must be put in place to prevent this. For example, schedule work activity so that no worker is working above another, and lower equipment and tools into the space *before* workers enter and remove them *after* workers leave the space.

Moving parts of equipment and machinery

Mechanical equipment such as augers, mixers, or rotating tanks can be dangerous if activated or not secured. Residual energy, such as gravity or accumulated pressure, may also pose a risk unless the equipment is locked out and de-energized. This must be done by following a written lockout procedure that is specific for each piece of equipment and that states each place where a lock must be applied. Even when the power is shut off and the equipment is locked out at control points, unsecured equipment can move, especially if it is out of balance.

Before doing any work in confined spaces:

- Shut the power off
- Ensure that the equipment is locked out at control points
- Test the lockout
- Secure any equipment that can move, even when it has been locked out

Hazard alert

Worker caught in ribbon blender inside tank

Two workers were cleaning a tank in a fish-processing plant. The tank had a ribbon blender that had not been locked out. One worker was given a water hose, which accidentally contacted the "on" switch for the ribbon blender. The worker suffered severe injuries to his lower body when the ribbon blender activated. Although other workers and emergency services tried to free him, he died while still caught in the blades of the ribbon blender.

Electrical shock

Electrical shock can result from defective extension cords, welding cables, or other electrical equipment. Work done in metal enclosures or in wet conditions can be particularly dangerous. Install ground fault circuit interrupters (GFCIs) or use assured grounding where there may be a danger of electrical shock. All electrical sources that pose a hazard to workers inside the space **must** be locked out following the written lockout procedure for the particular confined space.

BK80 guts COLOUR.indd 15 12/5/08 10:24:28 AM

Substances entering through piping

Piping adjacent to a confined space could contain liquids or gases or other harmful substances. If these substances enter the confined space, the hazards may include:

- Toxic gases
- Burns from hot substances
- Drowning
- Being trapped, crushed, or buried

Substances must be prevented from entering the confined space through piping. This is done by "isolating" the piping from the confined space. The method often involves disconnecting the piping or putting solid plates to block off the piping from the confined space. If valves are used to isolate the piping, a special double-block system must be used so that nothing can leak into the confined space. Section 9.18.1 of the Regulation describes exemptions to the prohibition on using valves alone to isolate piping.

Poor visibility

Poor visibility increases the risk of accidents and makes it harder for a standby person to see a worker who may be in distress. If poor visibility results from inadequate lighting, the light levels should be increased (although area lighting is not always required). If activities such as sandblasting or welding result in poor visibility, appropriate ventilation may be needed to reduce harmful substances in the air.

If portable lighting is used where there may be an explosive atmosphere, the lighting must be "explosion-proof." (The *Canadian Electrical Code* has a description of lighting that is approved for use in explosive atmospheres.)

Emergency lighting such as flashlights or battery-operated area units must be provided where necessary, so that workers can locate exits and escape

Temperature extremes

Special precautions are needed before workers enter equipment such as boilers, reaction vessels, and low-temperature systems. A qualified person must provide these procedures. Allow enough time for cooling of confined spaces that have been steam-cleaned.

BKE0 guts COLOUR.indd 16 12/5/08 10:24:28 AM

Noise

Noise produced in confined spaces can be particularly harmful because of reflection off walls. Noise levels from a source inside a small confined space can be up to 10 times greater than the same source placed outdoors. If the noise levels cannot be reduced, proper hearing protection **must** be worn where necessary.

Hazard alert

Noise causes hearing loss

A boilermaker removing tubes inside a heat exchanger with the aid of a pneumatic tool was exposed to 120 decibels of noise. This was sufficient to cause major temporary hearing loss after a few minutes of exposure.

Risk of drowning

Confined spaces should be fully drained or dry when entered. Spaces that are not fully drained or dry may pose a risk of drowning. The risk of drowning in a vat or tank with a large amount of liquid is easily recognized. However, workers have drowned in small pools of liquid. For example, insufficient oxygen, the presence of a toxic gas, or a blow to the head can make workers unconscious. Workers who have fallen face-down into a small pool of water have drowned.

BK80 guts COLOUR.indd 17 12/5/08 10:24:29 AM

Confined space entry program

Before workers perform work in a confined space, the employer **must** prepare and implement a written confined space entry program.

The identification, evaluation, and control of confined space hazards are often quite complex. For assistance in assessing the hazards and preparing a written confined space entry program, consult a qualified occupational health and safety professional. The health and safety professional can tell you what to do to make it safe to enter a confined space, including providing the appropriate air-testing equipment, and explaining the portable air-moving device and the personal protective equipment to be used.



A well-thought-out rescue plan, proper equipment, and training and practice sessions are key to keeping workers safe if they must enter a confined space.

The confined space entry program **must** include the following:

- An assignment of **responsibilities**.
- A list of each confined space or group of similar spaces, and a **written hazard assessment** of those spaces prepared by a qualified person.

BKB0 guts COLOUR.indd 18 12/5/08 10:24:29 AM

- **Written safe work procedures** for entry into and work in each of the confined spaces. Each procedure must be written specifically for each of the hazards that exist in each space during each entry.
- The **equipment** necessary for each entry must also be provided, including testing devices, air-moving devices, isolation and lockout devices, and personal protective equipment.
- A **signed** permit where required.
- **Training** of employees.
- A **rescue plan**.

REMEMBER!

Every worker has the right to refuse unsafe work. If you believe the space is unsafe to enter, do not enter it. Make sure all the safety precautions are in place.

BK80 guts COLOUR.indd 19 12/5/08 10:24:30 AM

Notes

BK80 guts COLOUR.indd 20 12/5/08 10:24:30 AM

WorkSafeBC Offices

Visit our web site at WorkSafeBC.com.

Abbotsford
2774 Trethewey Street V2T 3R1
Phone 604 276-3100
1 800 292-2219
Fax 604 556-2077

Burnaby
450 – 6450 Roberts Street V5G 4E1
Phone 604 276-3100
1 888 621-7233
Fax 604 232-5950

Coquitlam
104 – 3020 Lincoln Avenue V3B 6B4
Phone 604 276-3100
1 888 967-5377
Fax 604 232-1946

Courtenay
801 30th Street V9N 8G6
Phone 250 334-8765
1 800 663-7921
Fax 250 334-8757

Kamloops
321 Battle Street V2C 6P1
Phone 250 371-6003
1 800 663-3935
Fax 250 371-6031

Kelowna
110 – 2045 Enterprise Way V1Y 9T5
Phone 250 717-4313
1 888 922-4466
Fax 250 717-4380

Nanaimo
4980 Wills Road V9T 6C6
Phone 250 751-8040
1 800 663-7382
Fax 250 751-8046

Nelson
524 Kootenay Street V1L 6B4
Phone 250 352-2824
1 800 663-4962
Fax 250 352-1816

North Vancouver
400 – 224 Esplanade Ave. W. V7M 1A4
Phone 604 276-3100
1 888 875-6999
Fax 604 232-1558

Prince George
1066 Vancouver Street V2L 5M4
Phone 250 561-3700
1 800 663-6623
Fax 250 561-3710

Surrey
100 – 5500 152 Street V3S 5J9
Phone 604 276-3100
1 888 621-7233
Fax 604 232-7077

Terrace
4450 Lakelse Avenue V8G 1P2
Phone 250 615-6605
1 800 663-3871
Fax 250 615-6633

Victoria
4514 Chatterton Way V8X 5H2
Phone 250 881-3418
1 800 663-7593
Fax 250 881-3482

Head Office / Richmond
Prevention Information Line:
Phone 604 276-3100
1 888 621-7233 (621-SAFE)
Administration:
6951 Westminster Highway
Phone 604 273-2266
Mailing Address:
PO Box 5350 Stn Terminal
Vancouver BC V6B 5L5

After Hours
Health & Safety Emergency
604 273-7711
1 866 922-4357 (WCB-HELP)

R06/06

BK80 cover.indd 3 12/4/08 8:46:16 AM

R12/08 Printed in Canada BK80

BK80 cover.indd 4 12/4/08 8:46:16 AM